



**FURNITURE** 

email: info@riverside-furniture.com

Osborne Home Office Assembly Instructions

Page 2 of 2 Made in Viet Nam #12038





Note: To prevent possible damage to some type of flooring, never roll casters on unprotected hardwood or vinyl flooring. The lift mechanism is in a locked position for shipping. To unlock, pull straight out on the handle, and then the lift cylinder can be activated by lifting the handle.