

Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Separate, count and check all parts against the Parts List and Hardware List above.

To prevent possible scratches, assemble on a soft surface such as a blanket or carpet.

Step 1: Pivot the end of each metal strap attached on the bottom side of each Wood Base Cap (I). Place the Wood Base Cap on top of each leg of the Metal Base Frame (G). Pivot the metal strap back across the Wood Base Cap and reattach with the Screw and your Phillips Screwdriver. Repeat for all Wood Base Caps.

- Step 2: Press the Casters (H) into the holes of the Metal Base Frame.
- Step 3: Fit the bottom end of the Pneumatic Cylinder (F) into center of the Metal Base Frame as shown. Press down firmly on the Pneumatic Cylinder to secure. Place the plastic Covers onto the cylinder.



