













Components and Hardware List

Table Top	Table Top Leaf	Table Column	Top Stretcher	Bottom Stretcher	
					
(H-A) 1 pc.	(H-B) 2 pcs.	(H-C) 2 pcs.	(H-D) 1 pc.	(H-E) 1 pc.	
Ø8 x 40mm Allen Head Bolt	Ø8 x 85mm Allen Head Bolt	Ø9 x Ø13mm Lock Washer	Ø8 x Ø16mm Flat Washer	4 x 110mm Allen Key	4 x 100mm Allen Key
					
(H1) 6 pcs.	(H2) 7 pcs.	(H3) 13 pcs.	(H4) 13 pcs.	(H5) 1 pc.	(H6) 1 pc.



Rectangle Dining Table
23652

Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Separate and check all parts against the Components and Hardware List above.

To prevent damage, assemble on a soft surface such as a blanket or carpet.

Please note:

Do not fully tighten the bolts until the complete table has been assembled. Once the complete table is assembled, use the provided Allen Key to fully tighten all the bolts.

